Touch screen

By touching the screen with your finger, you can control the audio system and air-conditioning, adjust the screen display etc.

▶ Vehicles with navigation system

ILY31G019

▶ Vehicles without navigation system

ILY31G016

The “Information” screen shown in the above illustration is displayed when the INFO is pressed.

Switches	Page
"CLIMATE"	P. 190
"AUDIO"	P. 199
"INFO" (Displaying the "Information" screen)	P. 180
"DISP" (Adjusting the display)	P. 185
Trip Information. (Displaying the "Trip Information" screen)	P. 182
Maintenance	Navigation System Owner's Manual
Telephone	P. 267
Calendar	Navigation System Owner's Manual
"LEXUS Park Assist"	P. 150
Language	P. 184
Screen Setting	P. 187
Adjust Clock	P. 318/ Navigation System Owner's Manual

The initial screen

If the engine switch is set to "ACC" or "IG-ON" mode, the initializing screen will be displayed for a few seconds as the system starts up.

Trip information

Trip information such as driving time, driving distance, average vehicle speed, fuel consumption, etc. can be displayed on the screen. The displayed figure is for general information and may not always reflect precise and actual conditions.

■ Displaying the screen

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

- Consumption
  - After Refueling

    Displays the average fuel consumption since the vehicle was last refueled.
  - Cruising Range

    Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.
- Cruise
  - Average Speed

    Displays the average vehicle speed since the engine was started or the function was reset.

• Distance

Displays the total distance since the engine was stared or the function was reset.

n **Resetting the data**

Touching Reset will reset the “Average Speed” and “Distance”.

---

n **To avoid damaging the touch screen**

l Touch the screen lightly with your finger. If there is no response, remove your finger from the screen and try again.

l Remove any dirt on the screen by wiping with a soft cloth. Do not use detergent.

n **When using the touch screen**

l If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.

l The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, or remove your sunglasses.

Setting the touch screen

You can change the touch screen to your desired settings.

Language settings

The language used for all voice guidance, messages and touch screen switches may be changed.

STEP 1 Press INFO.

STEP 2 Touch Language on the "Information" screen.

STEP 3

Select the desired language.

STEP 4 Touch OK.

Turning off the beep sound

The beep that sounds when a touch screen button is touched can be turned off.

STEP 1 Press INFO.

STEP 2

Touch Beep Off.

Adjusting the display

STEP 1 Press .

STEP 2 Adjust the display as desired using R / − and G / +.

If you do not touch the screen for 20 seconds, the system will return to the previous screen.

▶ Vehicles with CD player

▶ Vehicles with DVD player

	R / −	G / +
Color	Red	Green
Tone	Lighter	Darker
Contrast	Weaker	Stronger
Brightness	Darker	Brighter

■ **“Day Mode”**

When the headlights are turned on, the screen dims. However the screen can be switched to “Day Mode”.

The screen will stay in “Day Mode” when the headlights are turned on until [Day Mode] is touched again.

If the instrument panel light control is set to “MAX”, “Day Mode” is not displayed.

■ **To turn off the picture display**

If [Screen Off] is touched, the screen display is turned off, and guidance is by voice only.

Screen settings

The following screen settings can be changed.

1 Automatic transition

20 seconds after air-conditioning or audio system use, the system will return the display to the previous screen.

2 Switch color

You can select the switch color.

3 Personal data deletion

The following personal data is deleted:

- User selection settings
- Phone book data
- Dialed numbers and received calls
- Speed dial
- Bluetooth® phone data
- Security code
- Maintenance conditions*
- Maintenance information "off" setting*
- Memory points*
- Areas to avoid*
- Previous points*
- Route trace*

*: If the navigation system is equipped

Setting automatic transition

STEP 1 Press INFO.

STEP 2 Touch "Screen Setting" on the "Information" screen.

STEP 3 Touch ON or OFF on the "Screen Setting" screen.

STEP 4 Press OK.

Setting the switch color

STEP 1 Press INFO.

STEP 2 Touch "Screen Setting" on the "Information" screen.

STEP 3 Touch Blue or Gold on the "Screen Setting" screen.

STEP 4 Press OK.

To delete personal data

STEP 1 Press INFO.

STEP 2 Touch "Screen Setting" on the "Information" screen.

STEP 3 Touch the "Delete personal data" on the "Screen Setting" screen.

STEP 4

Touch Delete.

Check carefully beforehand, as data cannot be retrieved once initialized.

- **When deleting personal data**

  Data can only be deleted when the vehicle is stopped.

- **When selling the vehicle**

  Be sure to initialize both the call history and personal data. (→P. 187)

- **If you touch the**

  The display returns to the previous screen.